




**Door Locations & Latches**

**Typical Hoistway Elevation**


## Concord Model Description:

The model number is a combination of the finished cab interior dimensions and the cab type.

### Sample: INFINITY Model 3548W (gated)


Elevator Name      Clear Inside (35" x 48")      Cab Type      Indicates Gated Model



**Standard Cab**

Standard cab configuration offers a single front entrance. Drawings include hoistway dimensions with adequate space for the cab gate.


Example: INFINITY Model 3548 (gated)



**Cab Type W  
(walkthrough)**

Cab type W offers both front and rear entrances. Drawings include hoistway dimensions with adequate space for the cab gates.


Example: INFINITY Model 3548W (gated)



**Cab Type S  
(side)**

Cab type S offers a single side entrance (either left or right). Drawings include hoistway dimensions with adequate space for the cab gate.

Example: INFINITY Model 3548S (gated)



**Cab Type WS  
(walkthrough side)**

Cab type WS offers both front and side entrances (either left or right). Drawings include hoistway dimensions with adequate space for the cab gates.

Example: INFINITY Model 3548WS (gated)